

# TECHNICAL NOTES



## **Sprinkler Loads on Trusses**

Released May 15, 2008

### **Introduction:**

Building Designers need to account for the weight of Fire Sprinkler Systems in addition to the load requirements imposed under the model building codes. Truss Designers are responsible for incorporating the additional load from the Fire Sprinkler Systems into the truss design.

The information in this *Technical Note* is applicable to both floor and roof systems. Only vertical loads from Fire Sprinkler Systems are discussed; lateral loads, where required, should be evaluated separately by a Registered Design Professional.

The requirements discussed are considered standard in the industry and are presented as a guide. Specific designs should be confirmed with the local building authorities, who may have unique regulations not addressed in this *Technical Note*. The guidelines provided in this *Technical Note* are not intended to exclude alternative solutions for specific projects that have been designed by a qualified Registered Design Professional.

### **Issue:**

Fire Sprinkler Systems may be used as an effective method of providing fire protection. When Fire Sprinkler Systems are used with truss systems, it is essential to design the trusses to carry the additional dead load and required live loads imposed by the Fire Sprinkler System. This *Technical Note* provides information to aid in the design of wood floor and roof trusses that are required to support Fire Sprinkler Systems.

### **Industry Recommendation:**

The Building Designer must provide the Truss Designer with a specified uniform load to account for the dead weight of the Fire Sprinkler System. He must also provide the location and magnitude of any concentrated dead loads required that are not covered by the uniform load. The value of these loads will typically depend on the size of the pipes being used, the layout of the system, design criteria provided by the Fire Sprinkler System designer or other qualified professional, the requirements of the local building code, and the Building Designer's own experience.

The Truss Designer should design the trusses for this additional uniform dead load and any concentrated dead loads that may be required (as specified by the Building Designer) to account for the weight of water-filled pipe. In addition to these dead loads, the Truss Designer should also design the trusses for a minimum 250 pound concentrated live load to be applied to any single fire sprinkler support point, but not simultaneously to all support points. The 250 pound live load need not be considered simultaneously

View all WTCA Tech Notes at [www.sbcindustry.com/technotes.php](http://www.sbcindustry.com/technotes.php)

WTCA • 6300 Enterprise Lane • Madison, WI 53719  
608/274-4849 • 608/274-3329 (fax) • [www.sbcindustry.com](http://www.sbcindustry.com)

with other live (i.e., roof, snow, wind, etc.), loads. For ease of application, typical truss design software allows the truss designer to specify this load and automatically have it applied to each panel and mid-panel point in separate load cases. This is a conservative approach, but one that insures that this live load has been covered for any variance in the installed location of the sprinkler system hangers from the planned location.

## **Appendix A**

### **Background & Analysis:**

#### **Background:**

The use of automatic Fire Sprinkler Systems in commercial, multifamily, and residential construction is intended to provide improved protection to a building and its contents from damage due to fire. It is also intended to provide improved protection from injury of the building's occupants. As metal plate connected wood truss usage has become more prevalent in all construction types, it is essential for the Building Designer to consider the loads imposed on the truss system and provide the Truss Designer with this information. This allows the Truss Designer to make provisions in the truss design for the structural effects of the Fire Sprinkler Systems.

The open webbing of truss construction makes it highly compatible with other building trades. Water lines for sprinkler systems can be run through the open webbing making maximum use of the available space and eliminating costs associated with drilling or the loss of headroom. Occasionally, a building's use or its contents demand a Fire Sprinkler System with special layout requirements and heavy main waterlines that cannot be compromised. Truss construction can easily be manipulated with adjustments to Panel Lengths and web configurations to accommodate most special requirements.

#### **Analysis:**

##### ***Truss Design Loads***

In addition to load requirements imposed under the model building codes, the Building Designer must include adequate additional dead load allowance in the truss design loads to provide for the weight of the Fire Sprinkler System. Such loads are generally expressed in pounds per square foot (PSF).

The Fire Sprinkler System can be supported from either the top chord or the bottom chord of the truss. Regardless of which chord the Fire Sprinkler System attachment will be on, the Building Designer must notify the Truss Manufacturer who will make special provisions for attachments and loads. Alternatively, concentrated loads for the sprinkler system may be given when attachment locations are known. While WTCA does not specify or recommend values for these loads, typical values used range from 1.5 to 6 PSF depending on the nominal size of the pipe and the hanger spacing. It is up to the Building Designer to specify the load values to be used and to communicate those values to the Truss Designer.

##### ***Installation Loads***

In addition to the dead load of the water-filled pipe, the trusses must be able to support a minimum concentrated live load of 250 pounds applied at the point of attachment. Since the truss is already designed to handle the dead loads from the Fire Sprinkler System, it only needs to be checked for the additional 250 pound live load. The 250 pound live load provision is intended to accommodate the weight of sprinkler installation personnel for a very short time, 10 minutes or less (load duration factor of 1.60). In keeping with this intention, the 250 pound load is to be applied to any single fire sprinkler support point, but not simultaneously to all support points. Also, the 250 pound load need not be checked simultaneously with other short duration live loads such as live, snow or wind loads. If multiple sprinkler lines are attached to the same truss, the 250 pound load should be applied at only one location at a time, representing only one worker on the individual truss. Each point of attachment on an individual truss should be evaluated to determine which load causes the most critical effect.

In residential sprinkler system installations, *NFPA 13D*<sup>1</sup> assumes that the system will use the domestic

---

<sup>1</sup> The 2007 edition of *NFPA 13D*, Standard for the Installation of Sprinkler Systems in One- and Two-Family Dwellings and Manufactured Homes, by the National Fire Protection Association (NFPA)

water delivery system and one may not need to account for additional dead loads. However, the truss designs and the Fire Sprinkler System design need to be coordinated to eliminate conflicts for sprinkler head location or pipe runs.

### ***Limitations and Provisions***

Resistance of truss chords and other structural elements to lateral loads shall be considered by the Building Designer.

Large diameter pipe lines (4 inches or greater), significant risers, and lines running parallel to trusses may require special design provisions and/or additional members.

Pilot holes are required for all screws. Locating supports within truss Panels containing chord splices should be avoided.

Screw and bolt sizes and other mechanical connections or parts thereof shall be sized in accordance with *NFPA 13*<sup>2</sup> or the applicable NFPA standard and the National Design Specification for Wood Construction (*NDS*<sup>®</sup>) by the American Forest and Paper Association. Alternative sizes may be used to meet specific project conditions provided that the intent of all applicable codes and standards are met and the design is accomplished by a Registered Design Professional.

There should be no more than one Fire Sprinkler System support attached to each truss Panel. If more than one Fire Sprinkler System support is needed in one Panel, special engineering is required and a Registered Design Professional should be contracted.

With the approval of the Truss Designer or other Registered Design Professional the accommodation of the sprinklers in the truss system may vary from that presented in this document.

### ***Structural Considerations***

Trusses are capable of supporting significantly higher loads at Panel Points than in the spaces between the Panel Points. The location of the pipe support in relation to the Panel Points of the truss is very important and should be included in the analysis.

The Building Designer or owner should provide the Truss Designer with as much information as possible about the Fire Sprinkler System prior to the truss design process. This will give the Truss Designer a more accurate estimate of the overall load so that prior to truss manufacturing and installation the Truss Designer can identify the locations of special support points to accommodate attachment of the Fire Sprinkler System.

---

<sup>2</sup> The 2007 edition of *NFPA 13*, Standard for the Installation of Sprinkler Systems, by the National Fire Protection Association (NFPA)

## **Appendix B: Key Definitions:**

### **BUILDING DESIGNER:**

The owner of the building or the person that contracts with the owner for the design of the framing structural system and/or who is responsible for the preparation of the construction documents. When mandated by the legal requirements, the Building Designer shall be a registered design professional.

### **FIRE SPRINKLER SYSTEM:**

A system of pipes and accessories that distribute and discharge water to protect a structure and its occupants from damage or injury due to fire. In a truss system, the pipes are usually supported by the truss top chords, although sometimes they may be suspended from the bottom chord.

### **PANEL:**

Chord segment defined by two adjacent panel points.

### **PANEL LENGTH:**

Horizontal distance between the centerlines of two consecutive panel points along the top or bottom chord.

### **PANEL POINT:**

Location on a truss where the web members and top or bottom chords intersect and are connected by metal connector plates.

### **REGISTERED DESIGN PROFESSIONAL (RDP):**

Architect or engineer, who is licensed to practice their respective design profession as defined by the legal requirements of the jurisdiction in which the building is to be constructed.

### **TRUSS DESIGNER:**

The person responsible for the preparation of the truss design drawings.

### **TRUSS MANUFACTURER:**

An individual or organization engaged in the manufacturing of trusses.

View all WTCA Tech Notes at [www.sbcindustry.com/technotes.php](http://www.sbcindustry.com/technotes.php)